
## 1) Right click on desktop windows start menu and select Powershell



2) ipconfig /all to check under the hood

Here we see DHCP is ——enabled so we know dynamically assigned

```
PS C:\Users\Administrator> ipconfig /all
Windows IP Configuration
  Primary Dns Suffix . . . . . . :
  Node Type . . . . . . . . . . . . . . . . . . Hybrid
  IP Routing Enabled. . . . . . . : No
  WINS Proxy Enabled. . . . . . . . . No
  DNS Suffix Search List. . . . . : hsd1.co.comcast.net
Ethernet adapter Ethernet:
  Connection-specific DNS Suffix . : hsd1.co.comcast.net
  Description . . . . . . . . : Intel(R) PRO/1000 MT Desktop Adapter
  DHCP Enabled. . . . . . . . . . . . Yes
  Autoconfiguration Enabled . . . . : Yes
  IPv6 Address. . . . . . . . . : 2601:281:d87e:6aa0::56a(Preferred)
  Lease Obtained. . . . . . . . : Wednesday, February 14, 2024 8:22:30 AM
  Lease Expires . . . . . . . . : Sunday, February 18, 2024 12:49:55 AM
  IPv6 Address. . . . . . . . . : 2601;281;d87e;6aa0;a066;22c9;f2f1;9f2e(Preferred)
  Link-local IPv6 Address . . . . . : fe80::dfdc:64db:3713:56e0%5(Preferred)
  IPv4 Address. . . . . . . . . . . . . . . 10.0.0.15(Preferred)
  Lease Obtained. . . . . . . . : Thursday, February 15, 2024 10:22:57 AM
  Lease Expires . . . . . . . . : Saturday, February 17, 2024 10:22:56 AM
  Default Gateway . . . . . . . : fe80::82da:c2ff:fe91:35d7%5
  DHCP Server . . . . . . . . . . : 10.0.0.1
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-2D-3C-C7-8C-08-00-27-B0-65-65
  DNS Servers . . . . . . . . . : 2001:558:feed::1
                                   2001:558:feed::2
                                   75.75.75.75
                                   75.75.76.76
                                   2001:558:feed::1
                                   2001:558:feed::2
  NetBIOS over Tcpip. . . . . . : Enabled
```

3) Next I opted to check my DNS which was being automatically assigned as we see here with an Interface Index of 5. The Interface Index is currently automatically assigned but we can assign this. However, in this instance it is unnecessary. It tells Windows how to prioritize but we only have the one so it isn't necessary.

## Input: Get -DnsClientServerAddress

To assign we then input: Set -DnsClientServerAddress -InterfaceIndex 5 -ServerAddresses ("75.75.75.75", "75.75.75")

```
PS C:\Users\Administrator> Set-DnsClientServerAddress -InterfaceIndex 5 -ServerAddresses ("75.75.75,75","75.75.76")
PS C:\Users\Administrator> _
```

4) Next we will assign a static IP. Prior to this you may want to use arp -a to avoid any potential IP conflicts (reference prior assignments)

Input: New-NetIPAddress -IPAddress 10.0.0.190 -DefaultGateway 10.0.0.1 -PrefixLength 24 -InterfaceIndex (Get-NetAdapter).InterfaceIndex

```
PS C:\Users\Administrator> New-NetIPAddress -IPAddress 10.0.0.190 -DefaultGateway 10.0.0.1 -PrefixLength 24 -InterfaceIndex (Get-NetAdapter).InterfaceIndex
IPAddress
                : 10.0.0.190
InterfaceIndex
               : 5
InterfaceAlias : Ethernet
AddressFamily
               : IPv4
                : Unicast
Type
PrefixLength : 24
PrefixOrigin
             : Manual
SuffixOrigin
             : Manual
AddressState
            : Tentative
ValidLifetime : Infinite ([TimeSpan]::MaxValue)
PreferredLifetime ; Infinite ([TimeSpan]::MaxValue)
SkipAsSource : False
PolicyStore
               : ActiveStore
IPAddress
               : 10.0.0.190
InterfaceIndex : 5
InterfaceAlias : Ethernet
AddressFamily
               : IPv4
Type
                : Unicast
PrefixLength
               : 24
PrefixOrigin
             : Manual
SuffixOrigin
             : Manual
AddressState
             : Invalid
ValidLifetime : Infinite ([TimeSpan]::MaxValue)
PreferredLifetime : Infinite ([TimeSpan]::MaxValue)
SkipAsSource : False
PolicyStore
               : PersistentStore
```

## 5) Lets confirm everything took with ipconfig /all

```
PS C:\Users\Administrator> ipconfig /all
Windows IP Configuration
  Host Name . . . . . . . . . : WIN-KG868040KOB
  Primary Dns Suffix . . . . . . :
  Node Type . . . . . . . . . . : Hybrid
  IP Routing Enabled. . . . . . . : No
  WINS Proxy Enabled. . . . . . . . No
Ethernet adapter Ethernet:
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Intel(R) PRO/1000 MT Desktop Adapter
  Physical Address. . . . . . . : 08-00-27-B0-65-65
  DHCP Enabled. . . . . . . . . . . . No
  Autoconfiguration Enabled . . . . : Yes
  IPv6 Address. . . . . . . . . : 2601:281:d87e:6aa0::56a(Preferred)
  Lease Obtained. . . . . . . . : Wednesday, February 14, 2024 8:22:30 AM
  Lease Expires . . . . . . . . : Sunday, February 18, 2024 12:49:55 AM
  IPv6 Address.....: 2601:281:d87e:6aa0:a066:22c9:f2f1:9f2e(Preferred)
  Link-local IPv6 Address . . . . : fe80::dfdc:64db:3713:56e0%5(Preferred)
  IPv4 Address. . . . . . . . . : 10.0.0.190(Preferred)
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . : fe80::82da:c2ff:fe91:35d7%5
  DHCPv6 IAID . . . . . . . . . . . . 84410407
  DHCPv6 Client DUID. . . . . . . : 00-01-00-01-2D-3C-C7-8C-08-00-27-80-65-65
  DNS Servers . . . . . . . . . : 2001:558:feed::1
                                     2001:558:feed::2
                                     75.75.75.75
                                     75.75.75.76
                                     2001:558:feed::1
                                     2001:558:feed::2
```

6) Now we should change the hostname for help of organization

We check with the cmdlet: hostname

Administrator: Windows PowerShell
PS C:\Users\Administrator> hostname
wIN-KG868040KOB
PS C:\Users\Administrator> \_

Then to change input Rename-Computer -NewName DC1

Administrator: Windows PowerShell

PS C:\Users\Administrator> Rename-Computer -NewName DC1

WARNING: The changes will take effect after you restart the computer WIN-KG868040KOB.

PS C:\Users\Administrator>

It will need to restart to take and then we confirm with inputting hostname one more time

PS C:\Users\Administrator> hostname DC1 PS C:\Users\Administrator>

## 7) To install Active Directory we next input

Install-WindowsFeature -name AD-Domain-services -IncludeManagementTools

```
PS C:\Users\Administrator> Install-WindowsFeature -name AD-Domain-services -IncludeManagementTools

Success Restart Needed Exit Code Feature Result

True No Success {Active Directory Domain Services, Group P...

PS C:\Users\Administrator>
```

Upon success we then input the following to complete the install of AD

Install-ADDSForest -DomainName TopLevel.local -DomainNetbiosName TopLevel -InstallDns

Note: TopLevel.local and TopLevel are what I chose to use in this example yours will reflect what you choose based off your requirements/need.

Then you will input the restore password which must be different then your administrator, followed by "A" to continue with install saying yes to all

```
Administrator: Windows PowerShell

PS C:\Users\Administrator> Install-ADDSForest -DomainName TopLevel.local -DomainNetbiosName TopLevel -InstallOns
SafeModeAdministratorPassword: ****************************


Confirm SafeModeAdministratorPassword: ************************

The target server will be configured as a domain controller and restarted when this operation is complete.

Do you want to continue with this operation?

[Y] Yes [A] Yes to All [N] No [L] No to All [S] Suspend [?] Help (default is "Y"): A
```

8) The install is now underway and when complete it will restart and update settings



9) Once complete you should now notice your domain when you go to login

